# SC-220




## Parts

| Sym | Part Code | Description | Q'ty | Int | Kit |
|---|---|---|---|---|---|
| 1 | - | SC-220 Tower | 1 | | |
| 2 | - | SC-220 Base | 1 | | |
| 3 | - | SC-220 Rubber | 4 | | |
| 4 | - | 1 1/4-7 UNC x 4.00 Bolt | 6 | | |
| 5 | - | 1 1/4-7 Washer | 12 | | |
| 6 | - | 1 1/4-7 Nut | 6 | | |
| 7 | - | 3/4-13 UNC x 3.00 Bolt | 32 | | |
| 8 | - | 3/4 Washer | 64 | | |
| 9 | - | 3/4 Nut | 32 | | |
| 10 | - | STRIKER Sticker | 2 | | |
| 11 | - | SC-220 Sticker | 2 | | |

For Decal and/or Tool Box information, please contact your Dealer

INT(interchangeability)
○ Interchangeable old ⇔ new
△ Interchangeable old → new
▲ Interchangeable old ← new
× Not interchangeable

# SC-220




## Parts

| Sym | Part Code | Description | Q'ty | Int | Kit |
|---|---|---|---|---|---|
| 1 | | SC-220 Base | 1 | | |
| 2 | SC07-11 | Bearing Plate | 1 | | |
| 3 | SC06-05 | Rotating Weight | 1 | | |
| 4 | * | Bearing Housing O-Ring | 2 | | S |
| 5 | SC07-10 | Bearing Housing | 2 | | |
| 6 | SC07-12 | Bearing Spherical Roller | 2 | | |
| 7 | * | Motor O'Ring | 2 | | S |
| 8 | SC05-04 | Permco Motor | 1 | | |
| 9 | SC12-04AS | Flow Control Block CP | 1 | | |
| 10 | SC12-04 | Flow Control Block | 1 | | |
| 11 | SC11-11 | Pressure Hose | 1 | | |
| 12 | SC11-12 | Return Hose | 1 | | |
| 13 | HHCS 3/4-10UNC x 2.000 | Bearing Plate Screw | 2 | | |
| 14 | Washer 1/2" LD | Bearing Plate Washer | 2 | | |
| 15 | Washer 3/4"LD | Bearing Housing Washer | 8 | | |
| 16 | HHCS 5/8-11unc X 2.500 | Bearing Housing Screw | 8 | | |
| 17 | N/A | Motor Mount Adapter | 1 | | |
| 18 | Washer 5/8" LD | Flow control Block Washer | | | |
| 19 | (4EA) 5/8-11UNC X 1.750" | Flow control Block Screw | | | |
| N/A | SC09-13 | Seat Kit | 1 | | |

Flow Control Block CP consists of (4) hose port adapters and control block

Seal Kit consists of the parts marked "S". (Individual seals NOT sold separately)

INT(interchangeability)
◯ Interchangeable old ⇔ new
△ Interchangeable old → new
▲ Interchangeable old ← new
× Not interchangeable